

Operator's Manual

Prodigi[™] Pro Control

6-10E Pro	6-10G Pro
10-10E Pro	10-10G Pro
7-20E Pro	7-20G Pro
10-20E Pro	10-20G Pro
20-10E Pro	20-10G Pro
20-20E Pro	20-20G Pro






MN-47965-EN

REV.06 01/25

For the most current manual, visit alto-shaam.com Die neueste Fassung des Handbuchs finden Sie auf alto-shaam.com Pour la dernière version du manuel, visiter alto-shaam.com Para obtener el manual más actual, visite alto-shaam.com Ga voor de meest recente handleiding naar alto-shaam.com

Manufacturer's Information

Copyright	© Copyright 1/25 by Alto-Shaam, Inc.
	All rights reserved.
	This manual or any portion thereof may not be reproduced or used in any manner whatsoever without the express written permission of Alto-Shaam, Inc.
Trademarks	All trademarks referenced in this documentation are the property of their respective owners.
Manufacturer	Alto-Shaam, Inc.
	P.O. Box 450
	W164 N9221 Water Street
	Menomonee Falls, WI 53052
Original instructions	The content in this manual is written in American English.





Enjoy your Alto-Shaam Prodigi™ Oven!

The Alto-Shaam Prodigi oven combines a steam and convection oven into one versatile unit and can serve a variety of cooking functions. Alto-Shaam's Prodigi ovens allow chefs to control humidity and temperature separately, with powerful results. The same oven can be used to dehydrate vegetables, roast pork, steam rice, smoke brisket and bake loaves of bread. The recipe management system with one-touch cooking provides complete control over the oven, allowing chefs and foodservice employees to select pre-programmed recipes for maximum consistency. To store and secure important information, a HACCP data system pairs up with an onboard USB port, so settings can be downloaded and saved for the future. When it's time to clean up, Alto-Shaam's automated cleaning system saves labor previously spent scrubbing the oven cavity. On the oven's exterior, a retractable hose gives you spray-washing power without opening the oven door.

Extend Your Manufacturer's Warranty

Register

Register your Alto-Shaam appliance online. Registering your appliance ensures prompt service in the event of a warranty claim.

Your personal information will not be shared with any other company. alto-shaam.com/warranty

Alto-Shaam 24/7 Emergency Repair Service

Call 800-558-8744 to reach our 24-hour emergency service call center for immediate access to local authorized service agencies outside standard business hours. The emergency service access is provided exclusively for Alto-Shaam equipment and is available throughout the United States through Alto-Shaam's toll free number.

Availability Emergency service access is available seven days a week, including holidays.



This page is intentionally left blank.



Manufacturer's Information	
Foreword3Enjoy your Alto-Shaam Prodigi™ Oven!	
Table of Contents5	
Safety7The Meaning of Signal Words7Appliance Description and Intended Use8Safety Precautions9	
Labels 13 Labels	
Operation21How to Turn On and Turn Off the Oven.21Icon Identification.22How to View and Set up WiFi Connection.25How to Set up an Ethernet Connection.28ChefLinc Installation Checklist.31How to Preheat the Oven.33How to Cook with Programmed Recipes.34How to Cook in Manual Mode.36How to Cook in Professional Mode.41How to Use the Multiple Timers.45How to Prepare the Smoker Box for Smoking.50How to Cook using the Delta-T Core Temperature Cooking Mode.56How to Cool Down the Oven.61How to Create a Recipe.63How to Modify, Duplicate, or Delete a Recipe.68	
How to Modify, Duplicate, of Delete a Recipe 1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.	
How to Change the Home Screen	



How to Enable and Use the Replay FunctionHow to Lock Recipe Editing, Manual Cooking,or the Settings ScreenHow to View Oven InformationHow to Download HACCP DataHow to Calibrate the Temperature Probe	99 .101 .102
Maintenance Maintenance Schedule How to Clean the Oven using Cleaning Tablets How to Clean the Oven using Liquid Clean (if equipped) How to Descale the Oven How to View the Cleaning Log How to Set the Cleaning Time How to Winterize the Oven	. 109 . 113 . 117 . 118 . 120
Troubleshooting Error Codes	125 . 125
Notifications Notifications Conditions for Ovens Installed in New York City	
Warranty Warranty	135 . 135
Declaration of Conformity	137



The Meaning of Signal Words

This manual contains signal words where needed. These signal words must be obeyed to reduce the risk of death, personal injury, or equipment damage. The meaning of these signal words is explained below.



DANGER

Danger indicates a hazardous situation which, if not avoided, will result in serious injury or death.



WARNING

Warning indicates a hazardous situation which, if not avoided, could result in serious injury or death.



CAUTION

Caution indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



Notice indicates a situation which, if not avoided, could result in property damage.



NOTE: Note indicates additional information that is important to a concept or procedure.



Appliance Description and Intended Use

Appliance description	Engineered for dependability, connectivity, and cost savings, Prodigi [™] combination ovens are an all-in-one solution for efficient and consistent food production. These ovens do the work of a convection oven, kettle, steamer, fryer, smoker and more. With advanced features and accessories, Prodigi combination ovens are designed to support—and connect—the most demanding kitchens.
Intended use	The appliance is intended for use in commercial establishments where all operators are familiar with the purpose, limitations, and associated hazards of this appliance. Any other use is prohibited. This appliance is intended to be used for commercial applications, for example in kitchens of restaurants, canteens, hospitals and in commercial enterprises such as bakeries, butcheries, etc., but not for continuous mass production of food.
Residual risks	This oven is manufactured using ISO-certified processes. The oven is designed with maximum safety in mind; however, there are residual risks to operators of this oven. Residual risks include exposure to heat and exposure to hot food products.
Possible misuse	Misuse of this oven includes loading the oven with anything other than a food product. Misuse also includes heating or cooking any food product that contains alcohol or other flammable substance.



Safety Precautions

Before you begin	Read and understand all instructions in this manual.
Electrical precautions	Obey these electrical precautions when using the appliance:
	 All electrical connections must be made by a qualified and trained service technician in accordance with applicable electrical codes.
	 Consult local codes and Specification Sheets for the electrical cable and breaker size.
	Power source must match voltage identified on appliance tag.
	 CE-approved appliances include an equipotential-bonding terminal marked with the equipotential symbol.
	For CE models, use a Type B current protection device that accommodates a leakage current of 30mA.
Gas precautions	Obey these gas precautions when using the appliance:
	Only use the oven when the exhaust hood is turned on.
	Keep the area around the oven clear of any obstructions that might slow down the flow of cooling air.
	Do not place objects near the oven's exhaust vents.
	Do not touch the exhaust vents while the oven is running or immediately after it has been turned off.
	Do not spray aerosols in the area of the oven during operation.
	Do not store flammable materials in the area of the oven.
Usage precautions	Obey these usage precautions when using the appliance:
	Only use this appliance for its intended use of heating or cooking food.
	 Always keep liquids, or foods that can become liquid when heated, level and at or below eye level where they can be seen.
	 Always open the oven door slowly. Escaping hot vapors or steam can cause injury.
	Use utensils and protective clothing such as dry oven mitts when loading and unloading the appliance.
	 Use caution when using the appliance. Floors adjacent to the appliance may become slippery.
	If the appliance is installed on casters, freedom of movement of the appliance must be restricted so that utility connections (including gas, water, and electricity) cannot be damaged when the appliance is moved. If the appliance is moved, make sure that all utility connections are properly disconnected. If the appliance is returned to its original position, make sure that any retention devices and utility connections are properly connected.
	Continued on next page

- Do not cover or block any of the openings of this appliance.
- Do not cover racks or any other part of this appliance with metal foil.
- Do not keep anything underneath the oven that could block the vents.
- Do not use this appliance near water such as a sink, in a wet location, near a swimming pool, or similar locations.

Maintenance Obey these maintenance precautions when maintaining the appliance: precautions Obey precautions in the manual, on tags, and on labels attached to or shipped with the appliance. Only clean the exterior of the appliance when oven is OFF. Do not store the appliance outdoors. Do not clean the appliance with metal scouring pads. Do not use corrosive chemicals when cleaning the appliance. Do not use a hose, water jet, or steam cleaner to clean the appliance. Do not use the appliance cavity for storage. Do not leave flammable materials, cooking utensils, or food inside the appliance when it is not in use. Do not remove the top cover or side panels. There are no user-serviceable components inside. **Operator training** Before using the appliance: Read and understand the operating instructions contained in all the documentation delivered with the appliance. Know the location and proper use of all controls. Keep this manual and all supplied instructions, diagrams, schematics, parts lists, notices, and labels with the appliance if the appliance is sold or moved to another location. Contact Alto-Shaam for additional training if needed. Operator Only trained personnel are permitted to use the appliance. They must meet the qualifications following qualifications: Have received proper instruction on how to use the appliance Are familiar with commercial kitchens and commercial appliances The appliance must not be used by: Persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision concerning use of the appliance by person responsible for their safety. People impaired by drugs or alcohol. Continued on next page

SAFETY

Continued from previous page

- Children should be supervised to ensure that they do not play with the appliance.
- Children shall neither clean nor maintain the appliance.

Condition of appliance	 Only use the appliance when: All controls operate correctly The appliance is installed correctly The appliance is clean The appliance labels are legible
Servicing the appliance	 Only trained personnel are permitted to service or repair the appliance. Repairs that are not performed by an authorized service partner or trained technician, or the use of non-factory parts, will void the warranty and relieve Alto-Shaam of all liability.
	To prevent serious injury, death or property damage, have the appliance inspected and serviced at least every twelve (12) months by an authorized service partner or trained technician.
	Contact Alto-Shaam for the authorized service partner in your area.
Noise emissions	Without hood system, a maximum 67 dB(A) was measured at 3.3 ft (1m) from unit.
	With hood system, a maximum 73 dB(A) was measured at 3.3 ft (1m) from unit.
Massachusetts compliance	In accordance with NFPA 54 for the Commonwealth of Massachusetts only: Where automatically operated appliances are vented through a ventilation hood or exhaust system equipped with a damper or with a power means of exhaust, provisions shall be made to allow the flow of gas to the main burners only when the damper is open to a position to properly vent the appliance and when the power means of exhaust is in operation.
Personal Protective Equipment (PPE)	Wear the following Personal Protective Equipment (PPE) while cleaning the appliance:
	Protective gloves
	Protective clothing
	Eye protectionFace protection



Use of restraining devices

A restraining device (tether) must be installed to any appliance that is hard-wired and mounted on casters. The tether must:

- Be secured to the building's structure.
- Limit the movement of the appliance so that no stress is transmitted to the electrical conduit.

A connection point for the tether is located on the back of the appliance.

A tether is not supplied by nor available from the manufacturer.

DANGER: Before starting the oven, make sure you do not detect the odor of gas.
If you smell gas:

Shut off the gas supply immediately.
Do not attempt to light any appliance.
Do not touch any electrical elements.
Extinguish any open flame.
Evacuate the area.
Use a telephone outside of the property and immediately contact your gas supplier.
If unable to contact your supplier, contact the fire department.



For equipment delivered for use in any location regulated by the following directive: 2012/19/EU WEEE

Do not dispose of electrical or electronic equipment with other municipal waste.



Labels

MADE IN U.S.A.	Made in U.S.A.
<u>SSSS</u>	WARNING Hot surface
A	WARNING Electrical shock hazard
	Security seal
	WARNING Burn hazard Always load liquids, or foods that can become liquid when heated, at an eye level where they can be seen.
Every Alto-Shaam product is precision calibrated prior to release from the factory to ensure accurate temperature control. CALIBRATION TECHNICIAN	Every Alto-Shaam product is precision calibrated prior to release from the factory to ensure accurate temperature control.
LA-36443-E	Equipotential terminal



LABELS

LA-38911	Drain water connection point.
LA-38910	Untreated, drinkable water connection point.
LA-38909	Treated, drinkable water connection point.
$\begin{tabular}{ c c c c c c c c c c c c c c c c c c c$	Capacities
Image: Construction of the second s	WARNING Fire hazard This oven is only for use with factory-supplied legs, casters, or base.





WARNING ADVERTENCIA AVERTISSENENT

Failure to follow cleaning instructions can cause injury or equipment damage. Clean oven only with Alto-Shaam concentrated cleaning tablets. Cleaner is caustic. Avoid contact with skin or eyes. Wear PPE. Read and understand the safety data sheet and the operator's manual before cleaning.



Sin os esiguen las instructiones de limpieza, puede sufri lesiones o daños en el equipo. Limpie el homo solo con las pastillas de limpieza concentradas de Alto-Shaam. El limpiador es cáusitico. Evite el contacto con la piel o los ojos. Use equipo de protección personal (Personal Protective Equipment, PPE). Lea completamente la hoja de datos de seguridad y el manual del operador antes de realizar la limpieza.

Pour écarter les risques de blessures ou de dégâts matériels, veiller à respecter les instructions de nettoyage. Nettoyer le four injuement avec les pastilles nettoyantes concentrées Alto-Shaam. Le produit nettoyante est cuasitgue. Eviter le contact avec la peau et les yeux. Porter un EPI. Lire et comprendre la fiche de données de sécurité et le manuel de l'utilisateur avant de nettoyer. *LA2888*

WARNING


Steam. Open door carefully.

WARNING

Failure to follow cleaning instructions can cause injury or equipment damage. Clean oven only with Alto-Shaam concentrated cleaning tablets. Cleaner is caustic. Avoid contact with skin or eyes. Wear PPE. Read and understand the safety data sheet and the operator's manual before cleaning.







WARNING

Electric shock hazard

Appliances with permanent electrical connections that are mounted on casters must be secured to building structure. Read installation instructions.



▲ WARNING/ADVERTENCIA/VERTISSENENT WARNING WARNING UTON Improper installation, adjustment, alteration, service or waintenance can cause properly damage, injury or death. Red the installation, operating and maintenance instructions thoroughly before installing or servicing the equipment. WW W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W W U N M Installation, djuste, modificación, reporación o martenimiento indecuado padris producir datas M Installation, juste, modificación, reporación o martenimiento indecuado padris producir datas M Installation (solate, modificación, reporación o martenimiento indecuado data marteniza indecuado datamartena cans da installator o repora elequipe. <th>WARNING Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing the equipment. Water and waste connection shall comply with the basic plumbing code of the Building Officials and Code Administrators International, Inc. (COCA) and the Food Service Sanitation Manual of the Food and Drug Administration (FDA).</th>	WARNING Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing the equipment. Water and waste connection shall comply with the basic plumbing code of the Building Officials and Code Administrators International, Inc. (COCA) and the Food Service Sanitation Manual of the Food and Drug Administration (FDA).
Image: Constraint of the	WARNING Fire hazard For use only on noncombustible surfaces. Maintain the correct clearances to combustibles.
508 mm 508 mm 102 mm	
COA #5760	Certificate of Approval number, Fire Department - City of New York.

LA-39312

NOTICE/AVISO/AVIS	NOTICE For trained personnel only: The installation manual and
For trained personnel only: The installation manual and the wiring diagram for this appliance can be found inside the oven attached to the opposite side of this panel. Solo para personal capacitado: El manual de instalación y el diagrama de cableado de este equipo se pueden encontrar dentro del horno, en el lado opuesto de este panel. Personnel formé seulement : Le manuel d'installation et le schéma de câblage de cet appareil se trouvent à l'intérieur du four attachés de l'autre côté de ce panneau. LA-38941	the wiring diagram for this appliance can be found inside the oven attached to the opposite side of this panel.
	WARNING
Electric Shock Hazard To reduce the risk of electric shock, do not remove or open cover. No user-serviceable parts inside.	Electric shock hazard
Feier servicing to qualified personnel. Qualified personnel: Disconnect power before servicing. Peligro de descarga eléctrica Para reducir el riesgo de descarga eléctrica, no retire ni abra la cubierta. No hay piezas en el interior a la que se les pueda realizar manienimiento. Devine el manterimiento Personal calificado: Desconacte la energía antes de realizar mantenimiento.	To reduce the risk of electric shock, do not remove or open cover. No user-serviceable parts inside. Refer servicing to qualified personnel.
Danger de décharge électrique Pour fédirie le risque dé décharge électrique, ne par ouvrir ni retirer le capot. Ne contient pas de pièces réparables par l'utilisature. Contier les réparations à du personnel qualifié. Personnel qualifié. Sectionnez l'alimentation avant toute intervention.	Qualified personnel: Disconnect power before servicing.
eAWG for supply connections. e only copper wires suitable for temperatures 2 90°C.	Note: This label is only used on UL-certified appliances that have 120V to ground wiring.
not connect to a circuit operating at performance of the second s	Use AWG for supply connections.
AWG para las conexiones de suministro. solo cables de cobre aptos para temperaturas mayores que 90 °C. concete a un circuito que funcione a más de 150 V CA a tierra.	
ra su uso en circuitos derivados individuales solamente. Iliser du calibreAWG pour les raccordements électriques. Iliser soutusiement des conducteurs en cuivre qui conviennent à des	Use only copper wires suitable for temperature less than or equal to 90°C.
npératures 290°C. pas raccorder à un circuit fonctionnant sous plus de DVCA par rapport à la terre. Ilser exclusivement sur des circuits de dérivation propres. LA-38852	Do not connect to a circuit operating at more than 150 VAC to ground.
	For use on individual branch circuits only.



ANSI Z21 with ANSI restraining connector AVIS: Poot fournies, et d'un co ANSI Z21 que la tra les instruc autorisient Sicherheit dürfen nu genomme Schlauchv Geröf mit gegen uni Aufstellun zu montie estándar, rápid que deberá in conector, fabricante <u>it</u> 寮一一 个符合A ANSI Z21.	221.41 — CSA 6.9. I must i greans to guard against tra a specified in the appliance voir être entretenu, cet appa l'un connecteur conforme à l'un connecteur conforme à to branchement rap 41 • CSA 6.9. II doit aussi ce cition soit transmise au conne characteur à branchement rap 41 • CSA 6.9. II doit aussi ce cition soit transmise au conne ions du fabricant. UNG: Gasanschuluß und In es Fachpersonal entsprecher bestimmungen durchgeführ e dann beweglich aufgestellt, e ann beweglich aufgestellt, e an	annector complying with disconnet device complying clisconted tevice complying clisconted tevice complying clisconted tevice complying clisconted tevice complying clisconter and the second tevice is manufacturer's instructions. Trail doit être equipé des roulettes la norme ANSI 221.09 - CSA 6.16 ide conforme à la norme omporter un dispositif empèchant tacteur, comme il est spécifié dans betriebnahme dürfen nur durch d'ar gultigen örtlichen t werden. Gasbetriebene Geräte angeschlossen und in Betrieb chuß mit einer flexiblen luß hergestellt wird und das it der Wand verankerte Kette) esichert ist. Für die bewegliche gelieferten Räder an den Geräten in un dispositivo de desconexión hon para evitar tensiones en el en las instrucciones del	 NOTICE: Use only factory-supplied casters when needed When this appliance includes casters, the following mus- also be installed: a connector complying with ANSI Z21.69 / CSA 6.16; a quick-disconnect device complying with ANSI Z21.47 CSA 6.9; a restraining device to guard against transmission of strain to the connector as specified in the manual.
<u>)</u>		<u>]</u>	Consult instructions for operation and use.
USA CN : China DE: Germany DK: Denmark. ES: Spain FR: France GB: Britain GR: Greece HU: Hungary HL: Hungary HL: Hungary HL: Netherland: PL: Poland RC: Romania RU: Russia SE: Sweeten SE: Sweeten	Consult the instruction manual before 遠欠進る(現職局 朱和定世行交破, 非故 力な) Gast Truuss nach Lokalen Richtlin werden. Siehe Gebrauchsanweisung Dette apparat skal installerers i overen ordentlig ventilation, Lass instruktion Este acylog os debe instalar en confo Consulte las instructiones antes den Imanvahlto. Totust käytööppaasee Cet appareil doit étre installed in con timanvahlto. Totust käytööppaasee Cet appareil doit étre installe din sou le manuel diristructions avant dinstal Tisis applance shall be installed in con Consult the instruction avanual before H eyacdratroam yng ouxasvuft pahras. Erta a keszüléktet a huly szabályszávók A keszűléktet a installat in confor Consultár unaudu de instruction in struction in szabályszávók A keszűlékt ta fi installat in confor Consultár a hungy kandas a kanda ka	當在通知地方, 笑著使用 (公務內, 语参考识用书, isen installerer werden, Es kann rul in gut geluifteten Bereichen verwenden vor dem installerer des Gerätes. Isstemmelse med de lokale vertragter og må kun bruges på et sted med men inden du installerer dete apparat. mindad con las mornas locales ys de debe usar sido en lugares bien ventile stalar este equipo. markhyksis moustanzen, ja sita sas kayttää almoastaan tiloissa, joissa on h e ennen luiteren asentamista. sespace bien aéré en conformité avec la réglementation en vigueur. Cons sespace bien aéré en conformité avec la réglementation en vigueur. Cons informity with the local regulations and used only in well ventilated locatio entralling this applane. va vivist en oujuk/oppuan tipoc touc consuoic, woweupuóck sen a yoény sespace bien helt neleptient, is crask joi seallozó helyeken szabad hazz voza át a hasenskisti útmutatot. Litarania dedle anortantiva locale e solo in aree ben ventilate. Pri litarania dedle anortantiva locale e solo in aree ben ventilate. Pri de handeldidou ou u dit apparati talteter. 2 Jokalprung prespisari Luywac velycenie w pomiesczeniach z dobrą ządzenia nadychy zaportaci się u sinstrukcje obsługi. 2 zakonia o nadych zaportaci się u sinstrukcje obsługi.	 local regulations and used only in well ventilated locations. Consult the instruction manual before installin this appliance. a b a a b b c <lic< li=""> c <lic< li=""> c c</lic<></lic<>



UNIT READY FOR NATURAL GAS 该设备可以使用天然气 LA-23732	Unit ready for natural gas.
UNIT READY FOR PROPANE GAS 设备可使用液化石油气 LA-23733	Unit ready for propane gas.



This page is intentionally left blank.



How to Turn On and Turn Off the Oven

Before you begin The oven must be connected to electric power.

- Make sure the gas supply is connected.
- Make sure the water supply is connected.

Turning on the oven

To turn on the oven, do the following.

Step	Action	
1.	Touch the ON/OFF button ①.	
		CT-TS-014421


The oven is now on.

Turning off the oven

To turn off the oven, do the following.

2. Touch and hold the ON/OFF button ① until the "Shut Down Options" screen displays. Touch "Shut down" ②.

The oven is now off.



Icon Identification



Icon	Icon name	Description
Ĵ	Manual cook	Touch to use manual cook mode.
=	Recipe book	Touch to browse recipes.
Ŷ	Lock	Touch to lock the control.
-;ó;-	Lights	Touch to turn on or turn off the cavity lights.
	Menu	Touch to view the control menu.
	Professional cook	Touch to use professional cook mode.
ß	Preheat	Touch to set a preheat temperature.
F	Cool down	Touch to set a cool down temperature.
	Back arrow	Touch to return to the previous screen.



} }}	Convection	Touch to select convection mode.
ىۋا(Combi	Touch to select combi mode.
ن	Steam	Touch to select steam mode.
Ø	Action	Touch to select an action step or touch to continue during the cooking process.
	Cook time	Touch to cook by time.
R	Probe	Touch to cook by probe.
	Humidity	Touch to set the humidity percentage.
(THE	Temperature	Touch to set the temperature.
offe	Fan speed	Touch to set the fan speed.
$\mathbf{\mathcal{F}}$	Power level	Touch to select the power level.
<u>ج</u> بی ۲	Cold smoke	Touch to cold smoke.
(F)	Hot smoke	Touch to hot smoke.
È	Grease collection	Touch to turn on or turn off grease collection.
Ê	Shelf timer	Touch to cook using multiple shelf timers.

OPERATION

	Dehydrate	Touch to use dehydrate mode.
	Rest	Touch to use resting mode.
A	Delta-T	Touch to use Delta-T mode.
	Reset	Touch to reset the chamber.
+	Plus	Touch to add stage or action.
	Recipe edit icon	Touch to edit a recipe.
	Save	Touch to save a recipe.
	Duplicate	Touch to duplicate a recipe.
\triangleright	Start	Touch to start a cook.
\times	Cancel	Touch to cancel a cook, preheat, and close screens.

How to View and Set up WiFi Connection

Before you begin

The facility must have WiFi.

Do not connect to a guest network.

Procedure


To set up WiFi, do the following.

Step Action

1. **Touch** the menu icon ①. The menu screen displays.




2. **Touch** the "Network" icon **(2)**. The "Network Status" screen displays.






3.	Touch the "Setup Network" setting (3)
3.	Touch the "Setup Network" setting ③. Image: Connection Type Not Connection Type Office Connection Setting Setup Network Image: Setup Network
4.	Touch the "WiFi" icon ④.
	The available networks will show on the screen. The color of the network icon indicates the strength of the signal for each network. Green = strong Yellow = medium Red = weak
	· la







Result

The procedure is now complete.



How to Set up an Ethernet Connection

Before you begin

The facility must have an Ethernet port.


You will need an Ethernet cable.

Procedure

To set up an Ethernet connection, do the following.

Step Action

1. **Plug** the Ethernet cord into the Ethernet port on the oven and the wall outlet.



2. **Touch** the menu icon (1). The menu screen displays.






3.	Touch the "Network" icon ②. The "Network Status" screen displays.								
		₩ 🗄) ଚ ·	× I		☞ Ē @	× Ξ		
			Ē	0		Network Status			
		Manual Cooking	My Recipe Library	Cleaning		Connection Type	Off 🔗		
		N	*	ø		Internet	Not ×		
		HACCP Data	Service	Settings		Cloud	Not ×		
		2	?	()		Update Server	$\frac{_{\rm Not}}{_{\rm Connected}} \times$		
		Network	Help	Info		Connection Setting	s		
						Setup Network	>		
		¢	(2)			IP	Not Connected		
			\sim			¢		CT-TS-01583	2

4. **Touch** the "Setup Network" setting **③**.

letwork Status			
onnection Type	Off ⊗		
nternet	Not ×		
Cloud	Not ×		
Jpdate Server	$rac{Not}{Connected} imes$		
Connection Settin			
ietup Network	$\langle \gamma \rangle$		
	3) innected		

5. **Touch** the "Ethernet" setting **(4)**. The "Ethernet Configuration" screen displays.








Automatic IP configuration, touch the check mark (s).

Manual IP configuration

OPERATION

7. For manual IP configuration, **touch** the "Configure IP" setting **(6)**. **Touch** "Manual" **(7)** and follow the prompts.



Result

The Ethernet connection is now set up.



ChefLinc Installation Checklist

Place this form with the oven's records.

Connectivity Pre-Installation Checklist

Will you connect the oven to the Internet using Wi-Fi or Ethernet?	Wi-Fi	Ethernet	Unable to answer
--	-------	----------	------------------

Wi-Fi Connections

Is the Wi-Fi network that is to be used a WPA2 secured network?	Yes	No	Unable to answer
Is this network also used to send and receive point of sale information (credit card data, register receipts)? This is NOT recommended for any installation.	Yes	No	Unable to answer
Have you been provided with the network name (SSID) for the oven to connect to?	Yes	No	Unable to answer
Have you been provided the password for the Wi-Fi network to be used?	Yes	No	Unable to answer
At the final location that the oven will be installed, can you connect to the Wi-Fi system with your phone?	Yes	No	Unable to answer
Using your phones Wi-Fi connection, are you able to connect to alto-shaam.com? You are testing for any additional security on the network to block access to external sites. You will need to turn off your cellular service on your phone to make sure you're using the Wi-Fi network.	Yes	No	Unable to answer

Ethernet Connections

At the final location that the oven will be installed, is there an open Ethernet port conveniently located?	Yes	No	Unable to answer
Is the Ethernet port live (providing Internet access)?	Yes	No	Unable to answer
Is the Ethernet harness accessory ordered with the unit?	Yes	No	Unable to answer
Is there site action required?	Yes	No	

Action required:



Connectivity Installation Checklist Refer to Network Status screen

What is your connection type?	Wi-Fi	Ethernet
What color is the network status icon?	Red Yellov	w Green
What is the Internet status?	Connected	Not connected
What is the cloud status?	Connected	Not connected
What is the update server status?	Connected	Not connected
What is the SSID (network name)?		
What is the password?		
What is the IP address?		
What is the Front End (FE) software version number?		
What is the Back End (BE) software version number?		
What is the Control Board (CB) software version number?		
Is this the latest software version?		
Validate via: https://www.alto-shaam.com/en/customer- support/software-downloads	Yes	No



How to Preheat the Oven

Before you begin

Make sure:

The oven is turned on.


The oven door is closed.

Procedure

To preheat the oven, do the following.

Step Action

From the manual cooking screen, **touch** the preheat icon ①.
 Enter the preheat temperature using the number pad. Touch the check mark.



Screen loading bars

The loading bar indicates the progress towards reaching the set temperature. If necessary, touch the cancel icon (2) to cancel the preheating process before the oven reaches its preheat temperature.



Result

The oven is preheating. When the preheat process is complete, the screen displays Ready.



How to Cook with Programmed Recipes

Before you begin

Make sure:

- The oven is preheated.
- Your food is prepared and ready to cook.

Procedure

To cook using a programmed recipe, do the following.

Step Action


1. **Touch** the recipe book icon ①. The browse recipes screen displays.



2. **Navigate** to the recipe.

Open the door and load the food into the cavity. **Close** the door.

Touch the recipe photo ②. The cooking process starts.





During the cooking process

The cooking status screen displays the details on the current cook setting. During the cooking process:

Action	Result
Touch the hand icon 💋 when action is required	to continue the cooking process.
Touch "X"	to cancel the cooking process.

Result


At the end of the cooking process, the oven sounds an alert and both the cavity light and door handle light flash. Remove the cooked food.



How to Cook in Manual Mode

Before you begin	Make sure your food is prepared and ready to cook.
Background	 This procedure consists of: setting a preheat temperature; setting the food loading action; and setting the cooking stage parameters (temperature, time, humidity, and fan speed).
Procedure	<section-header>To cook in manual mode, do the following. Step Action 1. Touch the manual cook icon ①. The manual cook screen displays. Image: Comparison of the street of the str</section-header>







4.

Cooking by time

OPERATION

If cooking by time, **touch** the cook by time icon ④. Then, **touch** the cooking time ⑤. **Enter** the cooking time using the key pad. **Touch** the check mark.



Cooking by probe


If cooking by probe, touch the cook by probe icon (6). Then, touch the probe temperature (7). Enter the probe temperature set-point using the key pad. Touch the check mark.



6. **Touch** the cooking temperature icon **(8)**. **Enter** the cooking temperature using the key pad.

Touch the humidity percentage icon **(9)**. **Enter** the humidity percentage using the key pad.

Touch the fan speed icon **(1)**. **Select** the fan speed.



- 7. **Touch** the plus (+) icon to add an additional step or action, if needed.
- 8. **Load** the food into the oven.
- 9. **Touch** the start icon (1). The cooking process timer starts to count down.





OPERATION

Continued from previous page

_

During the cooking process

Action	Result		
Touch the hand icon 🗭 when action is required	to continue the cooking process.		
Touch the chamber	to show the recipe details.		
Touch "X"	to cancel the cooking process.		
10. At the end of the cooking process, the oven sounds an alert, and the cavity light and door handle light flash.			
11. Open the door and remov	/e the hot food.		
NOTE: Be sure to remove the cooked food after the cooking process is complete. If left inside the oven, the food will continue to cook.			
The food is now cooked			

Result

The food is now cooked.



How to Cook in Professional Mode


Before you begin	 Make sure: The oven is preheated. Your food is prepared and ready to cook. 		
Background	 This procedure consists of: setting the food loading action; and setting the cooking stage parameters (temperature, time, humidity, and fa speed). 		
Procedure	To cook in professional mode, do the following. Step Action		
	1. Touch the professional cook icon ①. The professional cook screen displays.		
	2. Select a cooking mode ②. Image: Chamber I I I I I I I I I I I I I I I I I I I		



3. **Touch** the cooking temperature icon ③. **Enter** the cooking temperature using the key pad.

Touch the fan speed icon **(4)**. **Select** the fan speed.

Touch the humidity percentage icon (5). **Enter** the humidity percentage using the key pad.




4. If cooking by time, **touch** the cook by time icon **(6)**. Then, **touch** the cooking time **(7)**. **Enter** the cooking time using the key pad. **Touch** the check mark.






Cooking by probe

If cooking by probe, touch the cook by probe icon (8). Then, touch the probe temperature (9). Enter the probe temperature set-point using the key pad. Touch the check mark.



- 6. **Load** the food into the appropriate chamber.
- 7. **Touch** the start icon **(1)**. The cooking process timer starts to count down.





OPERATION

Continued from previous page

During the cooking process

Action Result			
Touch the hand icon 💓 when action is required	to continue the cooking process.		
Touch the chamber	to show the recipe details.		
Touch "X" to cancel the cooking process.			
8. At the end of the cooking light flashes.	process, the oven sounds an alert and the cavity		
9. Open the door and remov	ve the hot food.		
NOTE: Be sure to remove the cooked food after the cooking process is complete. If left inside the oven, the food will continue to cook.			

Result

The food is now cooked.



How to Use the Multiple Timers

Before you begin	Make sure:		
	The oven is preheated.Your food is prepared and ready to cook.		
Background	There may be times when you will want to cook multiple pans of food at the same time, but at different intervals. The dual timer function allows you to do so.		
Procedure	To cook using multiple timers, do the following.		
	Step Action		
	1. Touch the manual cook icon ①. The manual cook screen displays.		
	Image: Section of the se		



2. **Touch** the cavity (2). **Touch** preheat, a cooking mode or an action step icon (3) to choose the step type. ଳ୍ମ Ē Available B 222 225 3 8 ß ß CT-TS-015968 **NOTE:** Touching "Action" adds an action step to the recipe. An action adds manual tasks to be completed (\mathbf{i}) during the recipe such as loading the food or adding an ingredient. 3. The manual cook screen displays. The upcoming steps set the parameters for this screen. E ⋳ **₩** 1 Manual Cook Recipe Descriptio Instructions (North Combi Stage 1

> (00:01:00) (000%) (00:01:00) (000%) (000%) (000%)

> > 白

3

(F)

5

80

Pictures 〜 ・

63


0

4.	Touch the m	ultiple shelf icon ④.			
4.	Touch the m	ultiple shelf icon (4).	>>>	Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1 Image: Stage 1<	
	4	たtures ∽ ♪ + 圖 ▷		1 <u>Name</u> (00:05:00)	CT-TS-016392

5. **Touch** the cooking temperature icon (5). **Enter** the cooking temperature using the key pad.

Touch the humidity percentage icon **(6)**. **Enter** the humidity percentage using the key pad.

Touch the fan speed icon ⑦. **Enter** the fan speed using the key pad. The fan speed can be set in increments of five percent.





6. **Touch** the cooking time (8) for pan 1. **Enter** the cooking time using the key pad. **Touch** the check mark.



7. **Touch** the cooking time (9) for pan 2. **Enter** the cooking time using the key pad. **Touch** the check mark.



9. **Load** pan 1 into the oven.

Touch the start icon (11).

The cooking stage timer starts to count down for pan 1.




10. **Load** pan 2 into the oven.

Touch the start icon (12).

The cooking stage timer starts to count down for pan 2.

ු	Ē 6	ۍ ز ې	Ξ	
8	<u>}}</u>	350°F	\bigcirc	
1	00:05	5:00	D	
2	00:05	5:00	I C	5
3	00:05	5:00		603
4	00:05	5:00	\triangleright	\mathbb{Z}
5	00:05	5:00	\triangleright	

- 11. At the end of the cooking process, the oven sounds an alert and the cavity light flashes.
- 12. **Open** the door and remove the hot food.



Result

The food is now cooked.



How to Prepare the Smoker Box for Smoking

Before you begin Use only wood chips supplied by Alto-Shaam. Clean the smoker box of used wood chips. Dispose of the burnt wood chips as directed by local codes. Procedure To prepare the smoker box for smoking, do the following. WARNING: Fire hazard. The use of improper materials for the smoke function can result in a fire which may lead to personal injury or property damage. Only use wood chips supplied by Alto-Shaam. Action Step 1. **Soak** the wood chips in the clean water as instructed by National Fire Protection Agency Standard NFPA-96 or local codes. As of 2021, the NFPA-96 standard calls for a soaking period of 24 hours. WARNING: Fire hazard. Soaking the wood chips in anything besides clean water may lead to personal injury or property damage. Only soak the wood chips in clean water. Shake off excess water and place the moistened chips in the smoker box. 2. **Close** the smoker box lid. 3. **Install** the smoker box over the smoker element so that it rests in the cradle.

Result


The smoker box is now prepared for smoking.



CT-TS-016362

How to Hot Smoke in Manual Mode

Background	The smoking function can be used in convection mode or combination mode.
Before you begin	Make sure:
	The oven is preheated.
	Your food is prepared and ready to smoke.
	The wood chips have been soaked and the smoker box has been prepared for smoking. See topic <i>How to Prepare the Smoker Box for Smoking</i> .
Procedure	WARNING: Fire hazard. The use of improper materials for the smoke function can result in a fire which may lead to personal injury or property damage. Only use wood chips supplied by Alto-Shaam.
Procedure	To hot smoke in manual mode, do the following.
	Step Action
	1. Touch the manual cook icon ①. The manual cook screen displays.
	Image: Section of the section of





2. **Touch** the cavity (2). **Touch** preheat, a cooking mode or an action step icon (3) to choose the step type. ଳ୍ମ Ē Available B 222 225 3 8 ß ß CT-TS-015968 **NOTE:** Touching "Action" adds an action step to the recipe. An action adds manual tasks to be completed (\mathbf{i}) during the recipe such as loading the food or adding an ingredient. 3. The manual cook screen displays. The upcoming steps set the parameters for this screen. E ⋳ **₩** 1 Manual Cook Recipe Descriptio Instructions (North Combi Stage 1

> (00:01:00) (000%) (00:01:00) (000%) (000%) (000%)

> > 白

3

(F)

5

80

Pictures 〜 ・

63

0

4.

Cooking by time

If cooking by time, **touch** the cook by time icon ④. Then, **touch** the cooking time ⑤. **Enter** the cooking time using the key pad. **Touch** the check mark.



Cooking by probe

If cooking by probe, touch the cook by probe icon (6). Then, touch the probe temperature (7). Enter the probe temperature set-point using the key pad. Touch the check mark.






6. **Touch** the cooking temperature icon **(a)**. **Enter** the cooking temperature using the key pad.

Touch the humidity percentage icon **(9)**. **Enter** the humidity percentage using the key pad.

Touch the fan speed icon (1). **Enter** the fan speed using the key pad. The fan speed can be set in increments of five percent.



7. **Touch** the hot smoke icon (1).



- 8. **Touch** the plus (+) icon to add an additional step or action, if needed.
- 9. **Load** the food into the oven.





During the cooking process

Action	Result
Touch the hand icon 🐼 when action is required	to continue the cooking process.
Touch the chamber	to show the recipe details.
Touch "X"…	to cancel the cooking process.

- 11. At the end of the cooking process, the oven sounds an alert, and the cavity light and door handle light flash.
- 12. **Open** the door and remove the hot food.

NOTE: Be sure to remove the cooked food after the cooking process is complete. The oven will revert back to the preheat temperature. If left inside the oven, the food will continue to cook.

Result

The procedure is now complete.



How to Cook using the Delta-T Core Temperature Cooking Mode


Background	The Delta-T cooking mode cooks by internal product temperature with a probe. The Delta-T cooking mode increases the oven temperature in direct proportion to the internal temperature of the product. For example, the oven temperature will always be 100°F higher than the product itself. This slow cooking allows more time for enzymes to tenderize the meat. The Delta-T mode can be used with both convection mode and combination mode. Browning occurs toward the end of the cooking cycle.		
Before you begin	Make sure your food is prepared.		
Procedure	To cook using the Delta-T mode, do the following.		
	Step Action		
	1. Touch the manual cook icon ①. The manual cook screen displays.		
	Image: Section of the se		

Continued on next page


CT-TS-015965



ß







5. **Touch** the probe temperature (5). **Enter** the probe temperature set-point using the key pad. **Touch** the check mark.






6. **Touch** the Delta-T cooking temperature icon **(6)**. **Enter** the cooking temperature using the key pad.

Touch the humidity percentage icon **(7)**. **Enter** the humidity percentage using the key pad.

Touch the fan speed icon **(a)**. **Enter** the fan speed using the key pad. The fan speed can be set in increments of five percent.



- 7. **Touch** the plus (+) icon to add an additional step or action, if needed.
- 8. **Load** the food into the oven.
- 9. **Touch** the start icon **(9)**. The cooking process timer starts to count down.





OPERATION

Continued from previous page

During the cooking process

Action	Result	
Touch the hand icon 🔗 when action is required	to continue the cooking process.	
Touch the chamber	to show the recipe details.	
Touch "X"	to cancel the cooking process.	
10. At the end of the cooking	process, the oven sounds an alert, and the cavity	
light and door handle light flash.		
11. Open the door and remove the hot food.		

Result

The procedure is now complete.



How to Lock and Unlock the Screen

Before you begin	The oven is turned on.
Background	The screen can be locked to prevent changes being made during the cooking process.
Procedure	To lock and unlock the screen, do the following.
	Step Action
	1. Touch the lock icon ①. The screen is now locked.
	Image: solution of the solution of
	2. To unlock the screen, touch and hold the lock icon (1) and drag it to the left or right of the screen.
	Image: contract of the stretch.

Result

The screen is now locked or unlocked.



How to Cool Down the Oven

Procedure

To cool down the oven, do the following.

Step	Action
1.	From the manual cooking screen, touch the cool down icon ①.
	Enter the cool down temperature using the number pad. Touch the check mark. Open the door slowly to vent any steam for 3–5 seconds. Then, leave the door open 4 to 6 inches.
	WARNING: Burn hazard. Open the door carefully. Escaping hot vapors or steam can cause injury.
	NOTE: The oven activates the convection fan for the cool down process. The oven deactivates the convection fan when the cool down process is complete.
	Ready 1 × 507 2 507 2 507

Cooling down progress bars

The progress bar indicates the oven's progress towards reaching its cool down temperature.



CT-TS-015772

Result

The oven is now cooled down.



How to Create a Recipe

Background

Creating a recipe consists of:

- Setting the cooking stage(s) parameters (temperature, time, humidity percentage, and fan speed);
- setting an action step if desired such as adding an ingredient;
- naming the recipe;
- adding a description to the recipe;
- adding a photo to the recipe;
- and adding the recipe to a category.

Procedure

To create a recipe, do the following.

Step Action


1. **Touch** the recipe book icon ①. The browse recipes screen displays.



2. **Touch** the plus icon (2). The step type screen displays.








Continued on next page

CT-TS-014463


6. **Touch** "Recipe Description" **(6)**. The recipe description screen displays.

Enter the recipe description. **Touch** the check mark icon to return to the create recipe screen.




7. **Touch** the cook by time icon or cook by probe icon (7).

Touch the cooking time or probe set-point temperature **(8)**. **Enter** the cooking time or probe temperature using the key pad. **Touch** the check mark.







8. **Touch** the humidity icon **(9)**. **Enter** the humidity percentage using the key pad. **Touch** the check mark.



9. **Touch** the chamber temperature set-point icon **(1)**. **Enter** the chamber temperature set-point using the key pad. **Touch** the check mark.




10. **Touch** the fan speed icon (1) to set the fan speed. **Touch** the check mark.





11. Touch the plus icon (12) to add an additional stage or action.
 Touch the delete icon (13) to delete a stage or action.



- 12. **Scroll** to "Pictures" to add a photo to the recipe.
- 13. **Scroll** to "Categories" to add the recipe to a category.
- 14. **Touch** the save icon (4) when finished to save the recipe.



Result

A new recipe has been created.



How to Modify, Duplicate, or Delete a Recipe

Procedure

To modify, duplicate, or delete a recipe, do the following.

Step Action

2.

1. **Touch** the recipe book icon ①. The "Browse Recipes" screen displays.



Modifying

To modify a recipe, **touch** the recipe edit icon 2 of the desired recipe.



The first stage of the recipe displays. Scroll to the stage you want to modify.

- **Touch** the cook by time or cook by probe icon then modify the value using the key pad.
- **Touch** the humidity icon to modify the humidity percentage.
- **Touch** the chamber set-point icon to modify the chamber temperature.
- **Touch** the fan speed icon to modify the fan speed.

Touch the save icon 3 when finished.

Touch the trash icon to delete the stage, if desired.

Continued on next page

CT-TS-015989




CT-TS-015992

Continued from previous page

Duplicating

3. To duplicate a recipe, **touch** the duplicate recipe icon 4 of the desired recipe.

Touch the recipe to copy it. The recipe copy will display at the bottom of the recipe list. Edit the copied recipe as desired.




Deleting

4. To delete a recipe, **touch** the delete icon (5).



Select the recipe(s) that you want to delete. **Touch** the delete icon again.

Touch "Continue" to confirm that you want to delete the recipe(s).



Result

The procedure is now complete.



How to Create a Category

Background

A category allows the user to label and group recipes together. When viewing a recipe, the user can add a recipe to a category by touching the check mark next to the desired category. The categories can be viewed at the bottom of an existing recipe screen.

Each category must contain at least one recipe. A recipe can be assigned to multiple categories

Procedure

To create a category, do the following.


Step Action

1. **Touch** the recipe book icon (1). The "Browse Recipes" screen displays.




2. **Touch** the categories icon **(2)**. The "Browse Categories" screen displays.






3. **Touch** the plus icon (3) to add a category. The "Create a Category" screen displays.




4. **Enter** the category name. **Touch** the check mark (4). The category has been created.



- Duplicating
- 5. To duplicate a category, **touch** the duplicate category icon (5) of the desired category. **Touch** the category to copy it. The category copy will display next to the selected category.








Select the category that you want to delete. **Touch** the delete icon (6) again.

Touch "Delete" ⑦ to confirm that you want to delete the category.



Result

The procedure is now complete.




How to Backup or Restore Settings with a USB Drive

Before you begin


You will need a USB drive.

Procedure

To backup or restore settings with a USB drive, do the following.








4. Scroll to "System Backup & Update."

Touch "Backup Settings to USB" or "Restore Settings from USB" (4). The USB screen displays.





5.	Select the settings file (5). Touch the check mark (6).	
	NOTE: Subfolders can be set up on the USB drive from your computer. To import settings from a subfolder, touch a subfolder, select the settings file, then touch the check mark.	
		VMC-TS-016955

Loading the recipes The oven downloads or restores the settings. When the process is complete, touch the check mark ⑦ to return to the general settings screen. Remove the USB drive.



Result

The settings have now been saved to the USB drive or restored from the USB drive.



VMC-TS-010493

How to Backup Recipes to a USB Drive


Before you begin

You will need a USB drive.


Procedure

To backup recipes from the oven to a USB drive, do the following.







Continued on next page



ALTO-SHAAM





Touch the check mark (5) to save the recipes to the top level of the USB drive. 5.



NOTE: Subfolders can be set up on the USB drive from your computer. To save a file to a subfolder, touch a subfolder then touch the check mark.







Loading the recipesThe oven downloads the recipes onto the USB drive. When the process is
complete, the "Download successful" screen displays. Touch the check mark (6)
to return to the general settings screen. Remove the USB drive.



VMC-TS-010436

Result

The recipes are now saved to the USB drive.




How to Restore Recipes from a USB Drive


Before you begin

You will need a USB drive loaded with recipes.


Procedure

To restore recipes from the USB drive to the oven, do the following.









Restore Settings from USB

Backup Recipes to USB

Update System Software

 \bigcirc

from 11

Touch the check mark **(6)** to load the recipes to the oven.



Select the recipe file (5).

5.

NOTE: Subfolders can be set up on the USB drive from your computer. To load a file from a subfolder, touch a subfolder then touch the check mark.

Recipes.tar.gz

X 🛗 Q 🗸



Continued on next page

CT-TS-015874





Loading the recipes The oven loads the recipe file. When the process is complete, the "Recipes uploaded" screen displays. **Touch** the check mark ⑦ to return to the general settings screen. **Remove** the USB drive.



VMC-TS-010427

Result

The recipes are now loaded.




How to Import Images from a USB Drive


Before you begin


You will need a USB drive loaded with the images.

Procedure

To import images from the USB drive to the oven, do the following.









4. Scroll to "System Backup & Update."

Touch the "Import Image(s) from USB" (4) setting. The USB screen displays.







Loading the images

The oven loads the selected images. When the process is complete, the "Images uploaded" screen displays. **Touch** the check mark ⑦ to return to the general settings screen. **Remove** the USB drive.



Result

The images are now imported.



How to Update Software with a USB Drive

Before you begin

Make sure:

- The oven is on and cool to the touch (room temperature).
- You will need a USB drive with the updated software. To download the most up to date oven software and register for email notifications when new software versions are released, please visit <u>https://www.alto-shaam.com/en/customersupport/software-downloads.</u>
- Do not remove the USB drive during the update process.

Procedure


To update the software, do the following.

Step Action


1. **Touch** the menu icon ①. The menu screen displays.




2. **Touch** the "Settings" icon (2). The "General Settings" screen displays.










6. **Repeat** steps 1 through 4.

Touch "Update Front End Software (FE)" to update the user interface software. **Select** the ASFE.bin file **(B)**. **Touch** the check mark **(D)**. The oven loads the selected software. **Touch** the check mark **(D)** when the update is complete to restart the oven.



7. **Repeat** steps 1 through 4.

Touch "Update Control Board (CB)" to update the control board. **Select** the file (1). **Touch** the check mark (2). The oven loads the selected software. The oven verifies the file and then updates the CB. **Touch** the check mark (3) when the update is complete to restart the oven.





8.	Remove the	e USB dr	ive.					
9.	Touch the "Info" icon (4) to validate the software versions.							
		☆ €		× =		☞ 🖹 🖯	\approx \equiv	
			Ē	N]	System Info		
		Manual Cooking	My Recipe Library	HACCP Data		Model	VMC-F4	
		*	6)	3	1	Serial Number	xxxxx	
		Service	Settings	Network		BE Firmware Version	xxxxx	
		(?)	(i)			FE Firmware Version	ххххх	
		Help	Info			CB Firmware Version	ххххх	
				(14)		System Version	xxxxx	
						Framework Version	xxxxx	
						\mathbf{t}		VMC-TS-017291

Result


The software has now been updated.




How to Change the Home Screen

Procedure

To change the home screen, do the following.







Result


The home screen has now been changed.



How to Change the Temperature Scale


Procedure

To change the temperature scale from °F to °C and vice versa, do the following.






3. **Touch** the "Temperature Units" setting ③. The select temperature units screen displays.



4. **Select** your desired temperature scale.

Touch the check mark 4 to save the temperature scale setting.



Result

The temperature scale has now been changed.



How to Enable/Disable the Handle Light

Procedure

To enable the handle light, do the following.






3. **Scroll** to the "Handle Light" setting.

Touch the Handle Light button ③. **Touch** the check mark ④. The handle light is now enabled.

Repeat the procedure to disable the handle light.



Result

The handle light is now enabled/disabled.



How to Enable/Disable Automatic Preheat

Background

Enabling the automatic preheat function preheats the oven upon start up to the set preheat temperature. Make sure to set your preheat temperatures. See topic *How to Preheat the Oven*.


Procedure

To enable/disable automatic preheat, do the following.

Step Action




2. **Touch** the "Settings" icon (2). The "General Settings" screen displays.





3. **Touch** the "Auto Preheat" button ③. **Touch** the check mark ④. The automatic preheat function is now enabled.

Repeat the process to disable the automatic preheat function.



Result

The automatic preheat function is now enabled/disabled.



How to Enable and Use the Replay Function


Background

When a cooking process is complete, the replay function repeats the same cooking process when you touch the replay icon. The replay function can be used for a programmed recipe or manual cook.


Procedure

To enable the replay function, do the following.

Step Action



2. **Touch** the "Settings" icon (2). The "General Settings" screen displays.






3. **Scroll** to the "Temperature Settings."

Touch the Replay button ③. **Touch** the check mark ④. The replay function is now enabled.

Repeat the process to disable the replay function.



Using the replay function (if enabled)

4. When the cooking process is complete, the screen will say "Done". **Touch** the hand icon (5). **Remove** the food from the oven.

Load the next tray into the oven.

If the replay function is enabled, **touch** the replay icon **(6)** to repeat the previous cooking process.




Result

The procedure is now complete.



How to Lock Recipe Editing, Manual Cooking, or the Settings Screen



 \bigcirc

To lock recipe editing, manual cooking, or the settings screen, do the following.

Continued on next page


CT-TS-014432




Procedure

3. **Scroll** to the "Security Locks."

Touch the Lock Recipe Editing button ③. The "Enter passcode" screen displays.



4. Create a passcode ④ using the keypad. Touch the check mark ⑤.Touch the check mark ⑥ to lock recipe editing.



Result

The lock recipe editing, manual cooking, or the settings screen are now locked.

How to View Oven Information

Background This procedure is to be done through the touchscreen on the oven, not through the ChefLinc[™] oven management system.

The oven information screen shows the oven model, serial number, software version, and system information.

Procedure

To view oven information, do the following.


Step Action

1. **Touch** the menu icon ①. The menu screen displays.



2. **Touch** the "Info" icon (2). The "System Info" screen displays.

Scroll to view the oven model, serial number, software version, and system information.




Result

The oven's information has been viewed.




How to Download HACCP Data


Before you begin	Make sure:
	The oven is on, but not in a cooking mode.
	You will need a USB drive.
Background	HACCP data provides automated record keeping, set-point validation, recipes used, dates and times. The data is stored until the information is downloaded. Once downloaded, the information is removed from the oven's memory. Best practice would be to download the information every 30 days to a USB drive. The file format is plain text file (.csv). The file can be viewed in Microsoft® Excel.
Procedure	To download HACCP data, do the following.
	Step Action
	1. Touch the menu icon ①. The menu screen displays.



2. **Touch** the "HACCP Data" icon (2). The "HACCP Data" screen displays.







Loading the data The oven downloads the data onto the USB drive. When the process is complete, the "Download Successful" screen displays. **Touch** the check mark (5) to return to the menu screen. **Remove** the USB drive.



CT-TS-015925

Result

The HACCP data has now been downloaded.



How to Calibrate the Temperature Probe

Before you begin

Make sure:

- The oven is on, but not in cooking mode.
- You have a thermometer.
- You have a container filled with ice and water.

Procedure To calibrate the probe, do the following.

Step Action

1. **Insert** the probe and the thermometer in a container of ice water and allow the temperature to settle to 32°F (0°C).

2. **Touch** the menu icon (1). The menu screen displays.



3. **Touch** the "HACCP Data" icon **(2)**. The "HACCP Data" screen displays.



4.	Touch the calibrate probes icon ③.	
	☞ 🖻 🖯 🔅 ☱	
	HACCP Data Biscuits Connect	
	> 0.01/023 1.555 0.01	
		CT-TS-015913
5.	Compare the probe temperature reading against 32°F (0°C).	
	Touch the "+" or "-" symbols (4) until the temperature displayed is $32^{\circ}F(0^{\circ}C)$.	
	Touch the check mark (5).	
	☞ 🗈 💩 🔅 🚍	
	Probe Calibration	
	Chamber 1 probe xx° +	

NOTE: Touch the probe calibration data icon (6) to view the probe calibration history.

Result

The probe is now calibrated.

i)

Remove the probe from the ice water.

 \bigcirc

6.



CT-TS-015916

This page is intentionally left blank.



Maintenance Schedule

Requirements	 See topic <i>How to Clean the Oven</i>. Make sure the oven is cooled down and off—inside of chamber 140°F (60°C) or less.
Daily	For daily maintenance, do the following.
	Remove any spills with disposable paper wipes or a damp cloth.
	Wipe the outside of the oven with a damp cloth.
	 Wipe the oven gaskets with soap and water.
	 Inspect the oven gaskets for damage.
	 Wipe the front door glass.
	 Check the product probe.
	Check the screen for cracking or peeling. Contact Technical Service if needed.
Weekly	For weekly maintenance, do the following.
	Clean the entire oven. Make sure to use a non-abrasive nylon scrub pad.
	Do not spray the cleaner directly into the fan openings located in the rear of the oven.
	Inspect the door LEDs.
	Inspect the oven cavity for signs of grease/carbon buildup.
	Check behind the fan panel inside the oven cavity for signs of grease/carbon buildup.
	Check behind the fan panel inside the oven cavity for signs of scale buildup.
	Inspect the heat exchanger for any signs of major deformation. If there are signs of deformation, immediately remove from service and take corrective action.
	 Inspect the heat exchanger for any loose/disconnected pipes or flanges. If pipes or flanges are loose/disconnected, immediately remove from service and take corrective action.
	Inspect the convection elements for signs of cracking, deformation, or damage.
	Clean the ventless hood grease filters (if ventless hood is equipped).
Monthly	For monthly maintenance, do the following.
	Clean out the drip tray line.
	Check the supplied water filtration and change as needed.
	Check for software updates.
	Inspect and test the proper draining of the oven cavity.
	Inspect the drain lines for leaks or clogs.



- **Inspect** the oven cavity for any signs of scale buildup.
- Inspect the ventless hood paper filter (if ventless hood is equipped, replace as needed).
- **Test** the ventless hood drain for proper drainage and signs of leaking.
- **De-scale** as needed. See topic *How to Descale the Oven*.

Yearly

For yearly maintenance, do the following.

NOTE: Must be performed by a qualified professional.

- **Replace** the steam bypass hose.
- **Inspect** and test the humidity control.
- **Inspect** the cleaning system pump and hoses for leaks and proper operation.
- **Inspect** and test the proper draining of the oven cavity.
- **Inspect** all steam water injection lines and clamps for leaks or potential issues.
- Inspect the hand shower handle and hose.
- **Test** steam injection solenoid.
- **Test** condensate solenoid.
- Inspect the upper browning valve hose.
- Inspect the low pressure relief valve and hose.
- **Inspect** the convection element seal from the electrical compartment.
- **Inspect** the gas heat exchanger seal from the electrical compartment.
- Inspect wiring to heating elements. Re-tighten or secure as needed. Record the amp draw.
- Inspect the N6 oven temperature probe seal.
- **Check** operation of all electrical cooling fans.
- Check all electrical connections are properly connected and secure to the boards.
- Check door hinges and handles. Tighten, secure, or adjust as needed.
- **Run** the oven in convection mode and test operation.
- **Run** the oven in steam mode and test operation.



How to Clean the Oven using Cleaning Tablets

Precautions



WARNING: Burn hazard.

Wear protective gloves, protective clothing, eye protection, and face protection when handling oven cleaner. Do not open the oven door during the cleaning cycle.

NOTICE Do not use steel pads, wire brushes, or scrapers when cleaning.

Background

- The oven has five different cleaning modes.
- The rinse cycle (10 minutes).
- The light clean cycle (35 minutes).
- The medium clean (1 hour and 18 minutes).
- The heavy clean (2 hours and 5 minutes).
- The heavy plus clean (3 hours and 30 minutes).




Cleaning the oven	To clean the oven, do the following.		
	Step	Action	
	1.	Clean the door glass with Windex® or equivalent glass cleaner.	
	2.	Clean the door gasket with soap and water.	
	3.	Close the door.	
		Spray the exterior of the oven with stainless steel polish. Wipe the exterior of the oven with a non-abrasive scrub pad. Follow safety instructions on the bottle of the stainless steel polish.	
		NOTICEUse only non-caustic cleaners.Do not spray directly into the fan openings on the rear of the oven.Do not use cleaners that contain sodium hydroxide (lye) or phosphorus.	

Continued on next page




Prodigi™ ■ Operator's Manual ■ MN-47965 ■ Rev 6 ■ 1/25



5. **Touch** the "Cleaning" icon **(2)**. The Cleaning screen displays.









Insert the appropriate number of cleaning tablets into the drain.

Close the drain screen.




Touch the "Start" icon (4).

7. The oven heats to the required temperature for the cleaning cycle, then the cleaning cycle starts.







Result

The oven is now clean.



How to Clean the Oven using Liquid Clean (if equipped)

Precautions



WARNING: Burn hazard.

Wear protective gloves, protective clothing, eye protection, and face protection when handling oven cleaner. Do not open the oven door during the cleaning cycle.

WARNING: Fire hazard.



Do not operate the oven in a cleaning mode without the liquid cleaner connected, with a kink in the cleaning hose line, or with an empty liquid cleaner container. Failure to do so may result in poor oven cleaning, grease and/or carbon accumulating inside the oven cavity and increased risk of fire.

NOTICE Do not use steel pads, wire brushes, or scrapers when cleaning.

Background

The oven has five different cleaning modes.

- The rinse cycle (10 minutes).
- The light clean cycle (30 minutes).
- The medium clean (1 hour and 20 minutes).
- The heavy clean (2 hours and 6 minutes).
- The heavy plus clean (3 hours and 30 minutes).






To clean the oven, do the following.

Cleaning the oven

Step	Action
1.	Clean the door glass with Windex® or equivalent glass cleaner.
2.	Clean the door gasket with soap and water.

3. **Close** the door.

Spray the exterior of the oven with stainless steel polish. **Wipe** the exterior of the oven with a non-abrasive scrub pad. Follow safety instructions on the bottle of the stainless steel polish.




4. **Touch** the menu icon **()**. The menu screen displays.




5. **Touch** the "Cleaning" icon (2). The Cleaning screen displays.








8. The oven heats to the required temperature for the cleaning cycle, then the cleaning cycle starts.








Result

The oven is now clean.



How to Descale the Oven

Before you begin



Wear protective gloves, protective clothing, eye protection, and face protection when handling oven cleaner. Do not open the oven door during the wash or rinse cycle.

NOTICE Do not use steel pads, wire brushes, or scrapers when cleaning.

Make sure you have Alto-Shaam ScaleFree Descaling Powder (CE-27889).


Procedure

To descale the oven, do the following.

Step Action

1. **Place** 7 oz. (198 g) of Alto-Shaam ScaleFree Descaling Powder into the cavity drain.

Close the drain screen.



- 2. **Disconnect** the liquid cleaner hose, if equipped.
- 3. **Clean** the oven with a medium clean cycle. See topic *How to Clean the Oven Using Cleaning Tablets or How to Clean the Oven Using Liquid Clean.*
- 4. **Spray** the interior of the oven using the hand shower.
- 5. If necessary, **open** the interior fan guard and rinse down the area behind the panel.
- 6. **Run** a rinse cycle.

Result

The oven is now descaled.



How to View the Cleaning Log

Background


The cleaning log allows the user to view details about the previously completed cleaning cycles on the unit.

Procedure

To view the cleaning log, do the following.

Step Action


1. **Touch** the menu icon ①. The menu screen displays.



2. **Touch** the "Cleaning" icon (2). The "Cleaning" screen displays.



Continued on next page





The cleaning log has been viewed.




How to Set the Cleaning Time

BackgroundThe user can set a cleaning frequency to schedule when the unit will go through
a cleaning cycle. The cleaning frequency can be set by hours or day and time.


Procedure

To set the cleaning time, do the following.


Step Action



2. **Touch** the "Settings" icon (2). The "General Settings" screen displays.



3. **Scroll** ③ until "Cleaning Settings" displays. **Touch** the "Set Cleaning Frequency" ④ setting.




Setting the cleaning frequency hours

4. **Touch** the "Hours" setting (5) to set the cleaning frequency hours. **Enter** the desired hours using the key pad. **Touch** the check mark.



Setting the cleaning frequency day and time

5. **Touch** the "Date & Time" setting **(6)** to set the day and time for cleaning. **Touch** the check box **(7)** next to a day to set it. **Touch** the check mark.



Continued on next page




6. The "Set cleaning frequency time" screen will display.

Touch the "AM"/"PM" button 8 to choose whether the cleaning time is set for AM or PM.

Enter the time of day for the cleaning. **Touch** the check mark.

Touch the check mark on the "Set Cleaning Frequency" setting screen.



Result

The cleaning frequency has been set.



How to Winterize the Oven

Winterization	Winterization is required if the Combitherm oven is stored in a location where the ambient temperature falls below 32°F (0°C). Freezing temperatures can permanently damage internal components, especially if water is not completely drained from the unit before storage.	
Winterize the oven	To winte	erize the oven, do the following.
	Step	Action
	1.	Allow the oven to cool.
	2.	Drain all hoses, solenoids, and tanks (condensate and pump housing).
	3.	Flush RV antifreeze through the tanks and hoses.
		WARNING: Poison hazard. Use only RV antifreeze specifically intended for potable water systems. Flush system thoroughly as directed before putting back into use.
Restart the oven	4.	Inspect all hoses, and components connected to hoses, for signs or cracking or splitting.
	5.	Flush cold water through each hose and each solenoid for a minimum of two minutes.
	6.	Spray cold water directly into oven cavity drain for a minimum of two minutes.
		NOTICE Do not use pressurized water for this step. Use only the oven's hand shower.
	7.	Run a forced rinse cycle.
	8.	Inspect drained water to verify all RV antifreeze has been flushed through all hoses and tanks.
	9.	Run a 30-minute steam cycle and 30-minute clean cycle.

Result

The oven is now ready for operation.



This page is intentionally left blank.



Error Codes

Code	Component	Description	Troubleshooting steps
E-5	2 - Convection fan	Convection fan (upper) under speed	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-5	2 - Convection fan	Lower convection fan under speed	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-10	44 - Cavity sensor	Cavity sensor short	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-10	47 - Food probe	Food probe short	 Investigate food probe for damage. Replace if damaged. Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-10	52 - Steam injector	Steam injector sensor short	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-10	55 - Tank	Tank sensor short	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-11	44 - Cavity sensor	Cavity sensor open	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.



ALTO-SHAAM

TROUBLESHOOTING

ode	Component	Description	Troubleshooting steps
E-11	52 - Steam injector	Steam injector sensor open	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-11	55 - Tank	Tank sensor open	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-31	2 - Convection fan (Classic control)	Motor (upper) over temperature	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-31	2 - Convection fan (Classic control)	Lower motor over temperature	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-31	2 - Convection fan	Motor VFD (upper) over temperature	 Make sure cooling fan(s) are operating. Make sure exhaust vents are clean and fr of debris. Make sure oven clearances are met. Ambient temperature greater than 105°F (41°C).
E-31	2 - Convection fan	Lower motor VFD over temperature	 Make sure cooling fan(s) are operating. Make sure exhaust vents are clean and fr of debris. Make sure oven clearances are met. Ambient temperature greater than 105°F (41°C).
E-31	44 - Cavity sensor	Chamber over temperature	 If the oven has experienced an over temperature condition allow the oven to co down for a minimum of 30 minutes. Press the high limit reset button. Resume cooking operation. If error reappears contact service provider.
E-31	55 - Tank	Tank sensor over temperature	 If the oven has experienced an over temperature condition allow the oven to con down for a minimum of 30 minutes. Press the high limit reset button. Resume cooking operation. If error reappears contact service provider.

Code	Component	Description	Troubleshooting steps
E-31	8 - Control Board	Control board too warm	 Make sure cooling fan(s) are operating. Make sure exhaust vents are clean and free of debris. Make sure oven clearances are met. Ambient temperature greater than 105°F (41°C). Check the door gasket for damage and proper seal.
E-31	9 - Interface Board	Interface board too warm	 Make sure cooling fan(s) are operating. Make sure exhaust vents are clean and free of debris. Make sure oven clearances are met. Ambient temperature greater than 105°F (41°C). Check the door gasket for damage and proper seal.
E-44	8 - Control Board	Control board SPI bus warning	 Touch screen to acknowledge error Continue to use equipment Cycle equipment power before attempting to update software If error continues, contact service
E-55	56 - Vent valve	Vent (upper) not open	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-55	56 - Vent valve	Lower vent valve not open	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-62	2 - Convection fan	Motor VFD (upper) over current	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-62	2 - Convection fan	Lower motor VFD over current	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-66	2 - Convection fan	VFD (upper) error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.



TROUBLESHOOTING

Code	Component	Description	Troubleshooting steps
E-66	2 - Convection fan	Lower VFD error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-78	19 - Voltage sensor	Voltage monitor too low	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-78	2 - Convection fan	VFD (upper) under voltage	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-78	2 - Convection fan	Lower VFD under voltage	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-79	19 - Voltage sensor	Voltage monitor too high	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-79	2 - Convection fan	VFD (upper) over voltage	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-79	2 - Convection fan	Lower VFD over voltage	 Check to make sure the unit plug is fully seated in the electrical outlet. Reset the main circuit breaker for the oven. If error reappears contact service provider.
E-80	2 - Convection fan	VFD (upper) memory error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-80	2 - Convection fan	Lower VFD memory error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.

Code	Component	Description	Troubleshooting steps
E-88	1 - Heater	Gas ignition failure (upper)	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or turning off the breaker. Inspect the top of oven for anything blocking the exhaust flue of the oven. Make sure the ventilation hood is turned on and working properly. Make sure the gas line is properly connected to the unit and the gas shut off valve is in the open position. Resume cook operation. If error reappears turn the oven off, shut off the gas supply to the oven and immediately contact service provider.
E-88	1 - Heater	Lower gas ignition failure	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or turning off the breaker. Inspect the top of oven for anything blocking the exhaust flue of the oven. Make sure the ventilation hood is turned on and working properly. Make sure the gas line is properly connected to the unit and the gas shut off valve is in the open position. Resume cook operation. If error reappears turn the oven off, shut off the gas supply to the oven and immediately contact service provider.
E-90	1 - Heater	Gas blower failure (upper)	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-90	1 - Heater	Lower gas blower failure	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-93	8 - Control Board	State synchronization error between the interface board and control board	 Clear error by pressing the check mark on the display to accept the error. If the error persists contact Alto-Shaam Technical Support.
E-94	10 - Control Board Communications	Communication error between Interface Board and Control Board	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.

TROUBLESHOOTING

Code	Component	Description	Troubleshooting steps
E-94	2 - Convection fan	VFD (upper) communication error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-94	2 - Convection fan	Lower VFD communication error	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.
E-102	59 - Ventless hood	Ventless hood filter Fault	 Check if filters are installed. Check if filters are clogged. Check operation of hood fan.
E-105	6 - Chamber	Low water pressure	 Water supply not connected. Water supply is shut off. Water supply to unit blocked or obstructed (check filter).
E-109	6 - Chamber	Chamber high limit	 If the oven has experienced an over temperature condition, allow the oven to cool down for a minimum of 30 minutes. Press the high limit reset button. Resume cooking operation. If error reappears contact service provider.
E-606	6 - Chamber	Error during cleaning cycle	 Manually Clean Oven. Manually Rinse Oven. Ensure chemicals removed before use. Resume use of oven. If error repeats contact service provider.
E-999	48 - Personality handler	IB and CB dip switch settings not set correctly	 Power down control using on/off icon. Cycle power to the oven either by unplugging the unit or by turning the main power switch off and then back on. Resume use of oven. If error reappears contact a service provider.



Notifications

FCC ID: N6C-SDPAC IC ID: 4908A-SDPAC

NOTICE

Federal Communication Interference Statement (United States only)

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be colocated or operating in conjunction with any other antenna or transmitter.



Canadian Department of Communications Industry Canada Notice (Canada only)

This Class B digital apparatus complies with Canadian ICES-003.

FCC Rules, Part 15 / Industry Canada

This device complies with Part 15 of FCC Rules and Industry Canada licenseexempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference, including interference that may cause undesired operation of this device.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from a person's body.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

For product available in the USA/Canada market, only channels 1–11 can be operated. Selection of other channels is not possible. If this device is to be operated in the 5.15~5.25GHz frequency range, it is restricted to indoor environments only.

Antenna: Proprietary

Antenna gain information: Embedded Antenna: 3.25dBi (2.4 GHz), 5.0dBi (5 GHz)

Frequency Tolerance: +/-20ppm

WARNING

The FCC / The Industry Canada regulations provide that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



General Specifications

	•		
Chipset:	QCA9377-3, (Qualcomm Atheros)		
Host Interface:	Wifi: SDIO v3.0; BT: High Speed UART		
Operating Voltage:	3.30 VDC +/- 5%		
Operating Temperature:	-20 to +70 degrees C		
Dimensions:	18.0 x 13.0 x 2.2 mm (L x W x D)		
Connector Type:	52-pin proprietary		
Radio Specifications:	802.11b/g/n: 2.412–2.484 GHz;		
	802.11a/n: 5.18–5.825 GHz		
	BT: 2.402–2.480 GHz		
Link Rates (1 stream):	IEEE 802.11b: 1–11 Mbps		
	IEEE 802.11g: 6–54 Mbps		
	IEEE 802.11a: 6–54 Mbps		
	IEEE 802.11n HT20: 6.5–65.0 Mbps		
	IEEE 802.11n HT40: 13.5–135.0 Mbps		
	IEEE 802.11ac VHT20: 6.5–78.0 Mbps I		
	EEE 802.11ac VHT40: 13.5–180.0 Mbps		
	IEEE 802.11ac VHT80: 29.3–390.0 Mbps		
Modulation Modes:	OFDM (256QAM, 64QAM, 16QAM, QPSK, BPSK), DSSS (CCK, DQPSK, DBPSK), GFSK (1Mbps), π/4 DQPSK (2Mbps), 8DQPSK (3Mbps)		
Hardware Encryption:	WEP, WPA/WPA2 (TKIP/AES-CCMP), WAPI		
Quality of Service (QoS):	WMM, WMM-PS, 802.11e		
Japanese Security Standard	This oven cannot be connected directly to the telecommunications circuits (or public wireless LANs) of any telecommunication carriers (example: mobile communications carriers, fixed communications carriers, or Internet providers). In the case of connecting the oven to the Internet, make sure to connect it via a router.		



Conditions for Ovens Installed in New York City

- Operating instructions in the manual must be read and understood by all persons using the appliance. The person responsible for training of the operators is responsible for the safekeeping of the manual.
- Prior to installation, plans specifying the exact product name/model number and dimensions/specifications shall be filed with and approved by New York City Department of Buildings (DOB). A copy of DOB docketed (Stamped, numbered and dated) plans shall be transmitted to the Fire Department for review and approval, as applicable.
- Installation, maintenance, and cleaning procedures shall comply with all applicable New York City Fire Code, New York City Electric Code, New York City Construction Codes (including the Building Code and the Mechanical Code), and rules.
- The cooking equipment shall be used for light duty cooking ad food warming only, and shall be provided with catalyst to limit the emission of grease-laden air.
- The cooking equipment shall be installed in an area approved by the New York City Department of Buildings.
- Underwriters Laboratories, Inc.'s listing requirements and manufacturer's installation, operation and maintenance requirements shall be complied with.
- The cooking equipment (including filters and catalyst) shall be inspected, cleaned and replaced if necessary, by a qualified person holding a Fire Department Certificate of Fitness. They catalyst shall be maintained in proper working order. A record of such inspection and cleaning shall be kept on the premises for inspection.
- All installations are subject to inspection by representatives of the Bureau of Fire Prevention which may result in additional requirements being imposed.
- The Fire Department's condition of approval shall be provided to all New York City buyers, users and installers.
- Certificate of Approval number shall be plainly and permanently stamped or otherwise fixed upon each product by the manufacturer or the local representative of the manufacturer.
- The equipment's technology does not violate any patent, trade name, trade secret or other intellectual right.
- The Certificate of Approval does not constitute an endorsement or recommendation of the product by the Fire Department, but is a certification that the product is acceptable as of the date of issuance.
- The Fire Department may withdraw this approval at any time in the event there is a reasonable doubt that the product does not operate or perform as required by code, the conditions of the resolution or as represented in the application.
- Any end user who fails to comply with the conditions as outlined in this approval will be subject to enforcement action.



Warranty

Introduction	Alto-Shaam, Inc. warrants to the original purchaser only, that any original part found to be defective in material or workmanship will be replaced with a new or rebuilt part at Alto-Shaam's option, subject to provisions hereinafter stated.
Warranty Period	The original parts warranty period is as follows:
	For all other original parts, one (1) year from the date of installation of appliance or fifteen (15) months from the shipping date, whichever occurs first.
	The labor warranty period is one (1) year from the date of installation or fifteen (15) months from the shipping date, whichever occurs first.
	 Alto-Shaam will bear normal labor charges performed during standard business hours, excluding overtime, holiday rates or any additional fees.
	For the refrigeration compressor, if installed, the warranty period is five (5) years from the date of original installation of the appliance.
	For heating elements on Halo Heat® Cook and Hold ovens, the warranty period is for as long as the original owner owns the oven. This warranty period applies to units sold after 2/1/2009 and excludes holding-only ovens.
	To be valid, a warranty claim must be asserted during the applicable warranty period. This warranty is not transferable.
Exclusions	This warranty does not apply to:
	Calibration.
	 Replacement of light bulbs, rubber gaskets, grease filters, air filters, racks, jet plates, and/or the replacement of glass due to damage of any kind.
	 Equipment damage caused by accident, shipping, improper installation or alteration.
	Equipment used under conditions of abuse, misuse, carelessness or abnormal conditions, including but not limited to, equipment subjected to harsh or inappropriate chemicals, including but not limited to, compounds containing chloride or quaternary salts, poor water quality, or equipment with missing or altered serial numbers.
	 Equipment damage caused by use of any cleaning agents other than those recommended by Alto-Shaam, including but not limited to damage due to chlorine or other harmful chemicals.
	 Any losses or damage resulting from malfunction, including loss of food product, revenue, or consequential or incidental damages of any kind.
	 Equipment modified in any manner from original model, substitution of parts other than factory authorized parts, unauthorized removal of any parts including legs, or unauthorized addition of any parts.
	Continued on next page

ALTO-SHAAM.

- Equipment damage incurred as a direct result of poor water quality*, inadequate maintenance of steam generators and/or surfaces affected by water. Water quality and required maintenance of steam generating equipment is the responsibility of the owner/operator.
- Equipment damage incurred as a result of not following the required maintenance schedule published in the manuals for the equipment.

Conclusion

This warranty is exclusive and is in lieu of all other warranties, express or implied, including the implied warranties of merchantability and fitness for a particular purpose. No person except an officer of Alto-Shaam, Inc. is authorized to modify this warranty or to incur on behalf of Alto-Shaam any other obligation or liability in connection with Alto-Shaam equipment.

*Refer to the product spec sheet for water quality standards.



DECLARATION OF CONFORMITY Manufacturer: ALTO-SHAAM. Alto-Shaam, Inc. W164 N9221 Water Street Menomonee Falls, WI 53202-0450 U.S.A. **EQUIPMENT TYPE:** Household and Similar Electric Appliances **EQUIPMENT DESCRIPTION:** Commercial Steam Convection Ovens **MODEL NUMBER:** CTP6-10E, CTP10-10E, CTP7-20E CTP10-20E, CTP20-10E, CTP20-20E CTC6-10E, CTC10-10E, CTC7-20E CTC10-20E, CTC20-10E, CTC20-20E **APPLIED DIRECTIVES** LVD (Low Voltage Directive) 2014/35/EC MD (Machinery Directive) 2006/42/EC EMC - 2014/30/EC **APPLIED STANDARDS:** EN 60335-1:2012, EN 60335-2-42: 2003 + A1:2008 + A11:2012 EN 55014-1, EN 55014-2 EN61000-3-2, EN61000-3-3 F We the undersigned, hereby declare that the equipment specified above conforms to the above **Directives and Standards** HAAN Manufacturer Name: ALTO-SHAAM INC. NAME: Mrs. Christa Pieper TITLE: Certification Manager Corporate Seal SIGNATURE: DATE: Horil -2011 MISCON'



DECLARATION OF CONFORMITY

Manufacturer:

Alto-Shaam, Inc. W164 N9221 Water Street Menomonee Falls, WI 53202-0450 U.S.A.



EQUIPMENT TYPE:

Household and Similar Electric Appliances

EQUIPMENT DESCRIPTION:

MODEL NUMBER:

APPLIED DIRECTIVES

APPLIED STANDARDS:

()

Commercial Steam Convection Ovens

CTP6-10G, CTP10-10G, CTP7-20G CTP10-20G, CTP20-10G, CTP20-20G CTC6-10G, CTC10-10G, CTC7-20G CTC10-20G, CTC20-10G, CTC20-20G

LVD (Low Voltage Directive) 2014/35/EC MD (Machinery Directive) 2006/42/EC EMC – 2014/30/EC

EN 60335-1:2012, EN 60335-2-42: 2003 + A1:2008 + A11:2012 EN 55014-1, EN 55014-2 EN61000-3-2, EN61000-3-3

We the undersigned, hereby declare that the equipment specified above conforms to the above Directives and Standards

Corporate Seal

Manufacturer Name: ALTO-SHAAM INC. NAME: Mrs. Christa Pieper TITLE: Certification Manager SIGNATURE: DATE: April - 20 - 2



DECLARATION OF CONFORMITY

Manufacturer: Alto-Shaam, Inc. W164 N9221 Water Street Menomonee Falls, WI 53202-0450

EQUIPMENT TYPE:

EQUIPMENT DESCRIPTION:

MODEL NUMBER:

APPLIED UK REGULATIONS:



Household and Similar Electric Appliances

Commercial Steam Convection Ovens

CTP6-10E, CTP10-10E, CTP7-20E, CTP10-20E CTP20-10E, CTP20-20E, CTC6-10E, CTC10-10E, CTC7-20E, CTC10-20E, CTC20-10E, CTC20-20E

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012
- The Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2019

APPLIED STANDARDS:



EN 60335-1:2012 EN 60335-2-42:2003 + A1:2008 + A11:2012 EN 55014-1:2018, EN 55014-2:2016

We the undersigned, hereby declare that the equipment specified above conforms to the above Directives and Standards

Manufacturer Name: ALTO-SHAAM INC. NAME: Christa Pieper TITLE: Certification Manager

SIGNATURE: DATE: July, 26st 2021









Menomonee Falls, WI U.S.A. Phone 800-558-8744 | +1-262-251-3800 | alto-shaam.com

ASIA Shanghai, China Phone +86-21-6173-0336

AUSTRALIA Brisbane, Queensland Phone 800-558-8744

CANADA Concord, Ontario Canada Toll Free Phone 866-577-4484 Phone +1-905-660-6781 FRANCE Aix en Provence, France Phone +33(0)4-88-78-21-73

GMBH Bochum, Germany Phone +49 (0)234 298798-0

ITALY Padua, Italy Phone +39 3319273313

INDIA Pune, India Phone +91 9657516999 **MEXICO** Phone 262-251-3800 Ext. 6506

MIDDLE EAST & AFRICA Dubai, UAE Phone +971-4-321-9712

CENTRAL & SOUTH AMERICA Miami, FL USA Phone 262-251-3800 Ext. 6506